



High Chair Instructions



Important Information

Please make sure the straps are secure and are placed firmly around your child.

If the straps are loose or moveable, then you need to shorten and secure the straps at the back of the high chair as per the diagram. Make sure the straps are secured and cannot be moved.

Make sure the fastening at the front of the highchair is clicked in securely.

If you have any problems securing the straps, please contact Reception before use.

Your child should not be left unattended when using the high chair.